



# Gas Nitriding of Titanium

By Donald Jordan and Virginia Osterman

This preliminary study examines the effect of the partial pressure of nitrogen on case characteristics when gas nitriding titanium in a vacuum furnace.


Interest in solution gas nitriding and diffusion of nitrogen into the surface of titanium alloys as a means to inhibit adhesive wear (galling) while replacing heavier steel machinery parts has been increasing in applications involving moving components. The use of vacuum furnaces with partial-pressure nitrogen atmospheres provides a practical and economical means for titanium nitride case hardening. The need to establish a consistent, quality process requires knowledge of the specific vacuum furnace used and the effect of partial-pressure nitrogen, temperature, and time. This current study looks at the effect of partial pressure on the case hardness, depth, and surface chemistry of titanium alloy Ti-6Al-4V. Note: This study is ongoing, and more complete conclusions are planned to be published following further work.

## INTRODUCTION

For all of the known benefits of using titanium alloys, including high strength-to-weight ratios and excellent corrosion resistance, titanium, unfortunately, is known to exhibit poor tribological properties. That

is, it has a high coefficient of friction (COF) when in moving contact with many mating materials, resulting in poor sliding and adhesive wear resistance that leads to failure by galling. Owing to this, metal-to-metal applications encountering friction and wear considerations require a surface treatment for adequate serviceability. This is increasingly a topic of investigation as various segments of industry are searching to reduce moving mass in machinery components [1, 2].

One treatment for enhancing the tribological properties of titanium that has been researched for years is nitriding, which is performed by plasma or gas processes [3]. Nitrogen has great affinity and solid solubility in alpha titanium, which greatly increases hardness and strength [1, 3]. Gas nitriding, the topic of this study, is classified as a diffusion process whereby nitrogen gas dissociates and nascent nitrogen is adsorbed and diffused into the titanium matrix. This nitriding process is not a “coating”; it is a thermochemical heat treatment where nitrogen becomes an integral part of the titanium matrix. So unlike a coating, it does not have to initially bond well to function well; the case will not peel or flake away from the base metal.



The titanium/nitrogen phase diagram in Reference [3] shows that higher levels of nitrogen will form compounds of titanium and nitrogen that can be thought of as a hard ceramic. Provided the compound layer is not too thick and depending on its chemical makeup and service application, it can provide greatly enhanced wear performance. Below the surface compound layer is a diffusion zone that is solid solution strengthened by nitrogen. This adds support to the surface for sustaining higher application loads, and like other diffusion processes, the depth of the diffusion zone is dependent on the time and pressure of the treatment.

Titanium has an even stronger affinity for oxygen than nitrogen, making the purity of the nitriding atmosphere highly influential to the end results [1, 3]. Investigation into the formation of oxygen-enriched surfaces (at high levels forming alpha case) in vacuum heat treating titanium using a graphite-insulated vacuum furnace revealed that even at good commercial vacuum levels of  $5 \times 10^{-4}$  Torr, titanium became surface enriched with oxygen during heating to 1,450°F [4]. The study of the “gettering effect” of titanium

indicates that oxygen may be a constituent of the case structure when gas nitriding titanium in commercial vacuum furnaces. Depending on the amount present, oxygen in the nitride case is not necessarily a detriment. Oxygen interstitially strengthens titanium like nitrogen, and at a certain level, may contribute to enhanced wear performance in a given application. Ti-6Al-4V has been purposely thermally oxidized to increase wear properties and reportedly performed comparably well in a wear test study involving numerous surface engineering treatments [2].

Solar Atmospheres is developing processes for gas nitriding titanium in a vacuum furnace using partial-pressure nitrogen gas at elevated temperatures. Of interest are the effects of partial pressure on the case hardness, case depth, and the surface chemistry/crystalline phases of titanium alloy Ti-6Al-4V.

## EXPERIMENTAL DETAILS

Ti-6Al-4V sheet was cut into approximately 1.5-inch squares. The surface of the coupons was used as-received following a rigorous alcohol wipe; no surface blasting or polishing was performed prior to processing.

An all-metal (molybdenum) vacuum furnace with a cylindrical, vertical hot zone, 10" diameter x 18" high, was used for this study. Three titanium coupons used for each run were hung on separate molybdenum wires attached to the lid of the furnace. All cycles began after an initial pump down to  $2 \times 10^{-5}$  Torr to assure vacuum integrity. The parts were heated in a vacuum to 854°C (1,570°F), and partial-pressure nitrogen was introduced at 70 microns, 1 Torr (1,000 microns), and 630 Torr. Nitriding time was 10 hours for each pressure.

Hardness profiles for each run were measured using a Struers DuraScan and 25-gram load. Specimens were etched using 2-percent HF for metallographic analysis and total optical case depth measurement. The RJ Lee Group in




Figure 1: Average hardness profile for Ti-6Al-4V nitrided for 10 hours at 70 microns, 1 Torr (1,000 microns), and 630 Torr at 854°C

Monroeville, Pennsylvania, performed surface analyses using X-ray photoelectron spectroscopy (XPS) and X-ray diffraction (XRD). The intent of this study was to determine the influence of pressure selection as a means to control the formation of TiN, Ti<sub>2</sub>N, and Ti oxide.

## RESULTS AND DISCUSSION

The hardness profiles for the three pressures evaluated are presented in Figure 1. This shows that the hardness of the diffusion zone drops off sharply for the 630 Torr (A) and 1 Torr (B) nitrided specimens. The 70-micron (C) results are comparable to the near surface hardness (0.0005 inches or 12.7 μm) of the 630 Torr (A) results, but show a deeper, more gently sloping diffusion zone hardness. Note that the diamond indenter of the DuraScan is too large for the thin compound layers (10 μm range) to be accurately measured. (A nano-indenter hardness tester is needed and will be used in further study along with scratch hardness testing.)

After etching to reveal the microstructure, optical measurements were performed for each pressure, and the results are presented in Table 1. Tests A and B have comparable case depths, while Test C has a case depth about 60 percent deeper. The photomicrographs revealing the total case depths are shown in Figure 2. Higher magnification micrographs of Figure 3 show the thickness of the compound layer. The compound layer

Test	Test Pressure	Time hours	Total Case Depth Inches (μm)	Compound Layer Inches (μm)	Diffusion Zone Inches (μm)
A	630 Torr	10	0.002695 (68.45 μm)	0.000371 (9.42 μm)	0.002324 (59.03)
B	1 Torr	10	0.002878 (73.10 μm)	0.000405 (10.29 μm)	0.002473 (62.81)
C	70 microns	10	0.004560 (115.82 μm)	0.000461 (11.71 μm)	0.004099 (104.11)

Table 1

was comparable for all three pressures, yet the total case depth was deepest for the lowest pressure, corroborating the microhardness profile results.

Based on prior investigations of the heat treatment of titanium alloys [4], it was surmised that the deeper case at the lowest pressure may be attributable to a higher presence of residual water vapor in the hot zone, owing to a “stale atmosphere” (relatively poor quality vacuum). This would result in oxygen enrichment within the case when water vapor adsorbs and dissociates on the titanium surfaces. To confirm this hypothesis, surface analyses using X-ray photoelectron spectroscopy (XPS) and X-ray diffraction (XRD) were performed [5]. The main crystalline phases detected with the XRD scans at each pressure are listed in Table 2. Oxygen is present on the surface as the titanium suboxide,  $Ti_2O$ .

Normalized X-ray counts, see Table 3, can be used to determine the relative ratios of the compounds  $TiN$ ,  $Ti_2N$ , and  $Ti_2O$ . This reveals that the compound layer of sample C, processed at the lowest pressure, has the highest oxide concentration, 33 percent, of the three samples. The oxide concentration of sample A is 14 percent and 11 percent for sample B.

When processing at a low pressure of 70 microns, very little nitrogen flow is pumped through the furnace. Water vapor is inherently adsorbed in the hot-zone insulation and thus the low nitrogen flow becomes concentrated with water vapor upon heating. Further, 70-micron flow results in low furnace volume turnover. This ultimately results in higher levels of oxygen in the case. This result supports the hypothesis.

Samples A (14 percent) and B (11 percent) oxygen concentrations are comparable, owing to increased nitrogen pressures and gas flow rates resulting in greater dilution of water vapor by nitrogen. In order to maintain a pressure of 630 Torr (A), however, an almost completely closed vacuum at times leads to a decrease in the volume turnover at the highest pressure. This results in somewhat higher oxygen concentration at 630 Torr compared to 1 Torr.

## CONCLUSIONS

This preliminary study revealed that the partial pressure of nitrogen when gas nitriding Ti-6Al-4V in a vacuum furnace can have a significant effect on the nitrided case characteristics. Processing with low partial pressure of 70 microns resulted in a considerably higher amount of surface oxides being present in the compound layer compared to processing at higher pressures of 1 Torr and 630 Torr. The pressure and gas flow/turnover rate of nitrogen influences the “gettering ability” of titanium for oxygen during the nitriding process. The lowest pressure process resulted in a higher hardness profile and total case depth. This is considered attributable to oxygen being an interstitial strengthening element in titanium — just as it is nitrogen’s purpose in diffusion zone strengthening of the case.

Phase	Composition
Titanium (cubic structure)	Ti
Titanium Nitride	$Ti_2N$
Titanium (hexagonal structure)	Ti
Titanium Oxide	$Ti_2O$
Titanium Nitride	$TiN$

Table 2




Figure 2a: Micrograph for 630 Torr (A) at 200X showing a total case depth of 0.002695 inches (68.45  $\mu m$ )




Figure 2b: Micrograph for 1 Torr (B) at 200X showing a total case depth of 0.002878 inches (73.10  $\mu m$ )




Figure 2c: Micrograph for 70 microns (C) at 200X showing a total case depth of 0.00456 inches (115.82  $\mu m$ )




Figure 3a: Micrograph for 630 Torr (A) at 500X showing a compound layer of 0.000371 inches (9.42 μm)




Figure 3b: Micrograph for 1 Torr (B) at 500X showing a compound layer of 0.000405 inches (10.29 μm)




Figure 3c: Micrograph for 70 microns (C) at 500X showing a compound layer of 0.000461 inches (11.71 μm)

Maximum peak counts associated with phases identified in the sample							
Phase	~2θ°	Sample A		Sample B		Sample C	
		Counts	Normalized Counts**	Counts	Normalized Counts**	Counts	Normalized Counts**
Ti-Cubic	38.2	496	--	683	--	2429	--
Ti <sub>2</sub> N	39.3	2525	2.2	3222	3.1	395	0.1
Ti-Hexagonal	40.2	634	--	370	--	1501	--
Ti <sub>2</sub> O	40.5	416	0.4	429	0.4	228	0.1
TiN	42.6	294	0.3	175	0.2	251	0.1
Ti phases combined*	--	1130	1.0	1053	1.0	3930	1.0

\*Counts for both Ti-Cubic and Ti-Hexagonal were added together  
 \*\*Counts were normalized by dividing by the Ti-combined numbers

Table 3

At this point in the investigation, it is unknown to what extent oxygen may enhance or detract from the wear performance of the nitrided case. Wear requirements for a product tend to be application-specific, but some standardized wear tests are planned for further study of vacuum nitrided Ti-6Al-4V. Reference [3] mentions nitriding of race car steering racks (rack and pinion gearing) as well as engine valves and spring retainers. Solar Atmospheres has nitrided titanium alloy engine valves and spring retainers, in addition to gears designed for the next Mars expedition land rover. This latter application is germane to the gear industry, and the hope is that there is an increasing focus on reducing moving mass in machinery components, including gears. 🔥

## REFERENCES

1. Bloyce, A., Morton P.H., Bell T.; Surface Engineering of Titanium and Titanium Alloys, ASM Handbook Volume 5, Materials Park, OH, 1994; 835-851.
2. Bansal, D.G., Eryilmaz, O.L., Blau, P.J.; Surface Engineering to Improve the Durability of Ti-6Al-4V Alloy, Wear 271 (2011); 2006-2015.
3. Rolinski, Ed; Nitriding of Titanium Alloys, ASM Handbook 4E, Materials Park, OH, 2016; 604-621.
4. Jordan, D. and Osterman V.; Minimizing Alpha Case during Vacuum Furnace Heat Treating, HTPro, Advanced Materials and Processes, March 2016; 46-48.
5. RJ Lee Group, XRD Analysis of Nitrided Titanium Report presented to Don Jordan, July 15, 2016.

**ABOUT THE AUTHORS:** Donald Jordan, FASM, is corporate metallurgist for Solar Atmospheres and heads an R&D group that develops vacuum heat treatment processes. The group has focused on thermochemical surface enhancement treatments and has developed processes for low-pressure carburizing and vacuum purge gas nitriding. Solar is recognized as an authority on vacuum heat treatment and vacuum furnace technology. For more information, email Jordan at don@solaratm.com or visit www.solaratm.com.

Virginia Osterman is a senior scientist at Solar Atmospheres. She has a Ph.D. in chemistry and more than 20 years of professional experience in materials and materials processing. Her work in the Solar R&D group includes responsibility for design and improvement of vacuum heating processes for Solar Atmospheres and its customers. She has focused on raw material processing, most prominently, hydriding and dehydriding of titanium, tantalum, and niobium. She has developed and currently teaches an ASM course in vacuum heat treating, geared toward operators and non-scientists, offered at ASM headquarters twice a year. For more information, email Osterman at ginny@solaratm.com or visit www.solaratm.com.